

## PREPPING THE PAINT BEFORE INSTALLING THE FILM

### PREPARATION:

Clean area where TRACWRAP is to be installed. Wax and sealant does not need to be removed. Be sure edges where TRACWRAP will be wrapped such as the underside of the hood or wheel wells are free of grease, dirt, or any other contaminants.

---

## INSTALLING THE FILM

### WET INSTALLATION (SUITABLE FOR 1 PERSON INSTALLATION):

Begin by spraying the area with water. Tap water is acceptable (See Figure 1). Remove TRACWRAP from the backing paper and place on the wetted area. The TRACWRAP can be wetted also. Take a card, such as a credit card, and wrap in a towel, preferably microfiber, and squeegee the TRACWRAP down pushing water and air to the edges (See Figure 2). The TRACWRAP can be lifted and repositioned as needed though be sure to re-wet the film and area of installation each time the film is lifted. Stretch the film as needed around curves to conform the TRACWRAP to bumpers, curved hoods, etc.

**FIGURE 1**



**FIGURE 2**



### DRY INSTALLATION (BEST SUITED FOR 2 PERSON INSTALLATION):

Begin installing TRACWRAP starting at one side and working to the other. While one person stretches the film keeping tension (See Figure 3), press the TRACWRAP down with a hand/finger/micro-fiber (See Figure 4). The TRACWRAP can be lifted and repositioned as needed. Stretch the film as needed around curves to conform the TRACWRAP to bumpers, curved hoods, etc.

**FIGURE 3**



**FIGURE 4**



## CONGRATULATIONS! YOUR VEHICLE IS NOW PROTECTED.

TRACWRAP offers temporary road abrasion coverage for a variety of needs including: track days, autocross, off roading, road trips, RVS and towing. Thank you for choosing Tracwrap™ by XPEL.



---

## REMOVING THE FILM

### THE FILM MAY BE REMOVED AS FOLLOWS:

- Warm the film by parking the vehicle outside in the sunlight. You may also use a heat gun or hair drier to loosen the adhesive.
- Peel one corner of the film up with your fingernail.
- Pull the film towards you at a shallow angle less than 45 degrees (see figure 5). This angle is important to ensure sure that the adhesive comes off with the film rather than staying on the paint. The film should “stretch” off the car.
- If any adhesive is left on the car, use a general adhesive remover to help loosen it.
- See our Paint Protection Film Frequently Asked Questions page for more info. [CLICK HERE.](#)

**FIGURE 5**

