



XPEL Edge Prep Instructions

XPEL Surface Prep is designed to shave valuable time off your paint protection installations. Working as an adhesive promoter, the Surface Prep gives you a variable adhesion level, allowing you to choose where you need a faster tack versus where you need a more forgiving adhesion. By increasing the existing tack by about 300%, notoriously painstaking edges and difficult contours lay down with the initial squeegee stroke. XPEL Surface Prep virtually eliminates the "detailing" or "finishing" process at the end of each install saving you time and money.

Directions:

1. Ensure that the surface is clean and dry.
2. Do not pour or spray directly onto the surface.
3. Apply a small amount of product on a microfiber or terry cloth towel and wipe the edge of the installation area only (do not apply directly to XPEL PPF)
4. Only apply the product to the areas where extra adhesion is required. Do not apply to the entire surface.
5. Allow the product to dry before installing XPEL PPF

Caution:

- Keep away from sparks & open flames
- Use with adequate ventilation
- Avoid prolonged breathing of vapors

Harmful if swallowed. If ingested, induce vomiting immediately. Seek medical attention in the event of dizziness or sickness. Avoid contact with eyes. In case of contact, flush eyes thoroughly for 15 minutes with cool water. Avoid prolonged contact with skin. Wash from skin with mild soap and water.