



CODING YOUR NEW REMOTE TO THE RECEIVER BOARD

1. Push and release the learn (SW) button on the receiver (RX) board. A red LED should flash slowly for 5 secs;
2. Within those 5 seconds, push and hold your desired button on the new remote for 2-3 secs or until the LED on the receiver illuminates steady for 1 second indicating successful coding.
The LED then resumes flashing for another 5 secs, during which period another radio control can be stored;
3. Wait 20 seconds for the system to exit the learning mode before testing your new remote to make sure it has been coded successfully.
4. Repeat this procedure for every remote to be coded.

