



BUILD STEPS:

1. CUT OFF STICK TO DESIRED LENGTH
2. STACK UNDERPASS-X CONES ON HOCKEY PUCKS
3. PLACE AT THE DESIRED SPACING
4. INSERT CUT STICK INTO CONES (PRESS FIRMLY) ENSURE DESIRED SPACING
5. MARK HOLE LOCATIONS BASED ON SHOWN DIMENSIONS
6. PREDRILL .0625 (1/16) HOLES THRU STICK AND CONE
7. WHILE HOLDING THE STICK FIRMLY IN PLACE DRIVE 3.250 INCH SCREW DOWN THRU THE STICK AND INTO THE PUCK
8. RUN IT LIKE A RENTED MULE!

PRO TIPS

- SET CLUTCH ON DRIVER TO PREVENT STRIPPING OF THREADS
- STAND ON THE STICK WHEN DRIVING THE SCREWS HOME TO ENSURE ITS TIGHT
- USE A FINISH WASHER FOR CARBON TWIGS OR TO ADD A TOUCH OF CLASS.