
3921 B Street NW Auburn, Wa USA 98001



P.O. Box 1497 Auburn, WA USA 98071-1497

www.gittspring.com - 253-833-6806 - 1-800-228-2861 - Fax 253-735-5892



### **How to Measure U-bolts**

"A" = Diameter (see wrench chart below).


"B" = Inside width between the legs of the U-bolt.

"C" = Length from inside the bend to the bottom of the U-bolt.

And Type of Bend. Square Bend, Round Bend or Semi Round and model of Vehicle.

### **Custom Made U-Bolts On Demand**

From 3/8 to 1 1/4 excluding Forged Top.



## **Wrench Size Chart for U-bolt Deep Nuts**

Bolt & Nut Diameter	Wrench Size	Bolt & Nut Diameter	Wrench Size	Bolt & Nut Diameter	Wrench Size
3/8	9/16	5/8	15/16	1 1/8	1 9/16
7/16	11/16	3/4	1 1/16	1 1/4	1 3/4
1/2	3/4	7/8	1 1/4		
9/16	7/8	1	1 7/16		

# **U-Bolt Torque Chart**

### **Do Not Re-Use U-Bolts**

All values below are general guidelines. The OEM Service Manual on specific models always takes precedence over values shown. U-bolts that have been torqued to a set preload are recommended to be re-torqued after a short time to take-up the stretch in the set of the material. U-bolts must be tightened and torqued using a cross pattern. Suggested Torque Values for Cold-formed U-Bolts with a light oil finish.

Size (Dia x Thread)	Material Grade	Torque (Ft. Lbs)	Size (Dia x thread)	Material Grade	Torque (Ft. Lbs)
3/8 x 24	<b>T</b> 5	28-38	3/4 x 16	Т8	279-330
7/16 x 20	<b>T</b> 5	44-58	7/8 x 14	Т8	441-511
1/2 x 20	Т5	66-84	1 x 14	Т8	665-757
9/16 x 18	Т5	93-116	1 1/8 x 12	Т8	943-1059
5/8 x 18	Т8	161-197	1 1/4 x 12	Т8	1300-1443