

COREBOOT

Field Installation Instructions

Engineered watertight seal for PVC-to-concrete pipe and wall connections.

Instructions for Core Drilling and Sealing

1. Core drill hole to specified size (see chart below)
2. Inspect and patch surface if required (Surface must be smooth, clean, and free of voids or honeycombing)
3. Insert CoreBoot flush to concrete surface
4. Tighten bolts in star pattern until snug
5. Insert PVC pipe to internal stop ring
6. Final tighten bolts until slight plate deflection is achieved
7. Tighten gear clamp
8. Confirm no movement — installation complete

Drill & Pipe Size Chart

CoreBoot Size		Accepted PVC Pipe Type	Core Drill Size
Imperial	Metric		
4"	100mm	4" DR28, DR35	6"
5"	125mm	5" DR28, DR35	8"
6"	150mm	6" DR28, DR35	9"
8"	200mm	8" DR35	11"
10"	250mm	10" DR35	13"
12'	300mm	12" DR35	15"

Installation Tools Required

1/2" Socket, 5/16" nut driver

