




GROUNDING & BONDING

WHY IS IT SO
COMPLICATED?
BY
PAUL MELVIN
K4PGM









Where it all began!

Telegraph was the first nationwide electrical system.




GROUNDING & BONDING EXPLAINED

- Grounding is the connection of the electrical circuit to the earth.
 - This allows a safe means for unused current to be returned to the source and removed from conductive surfaces.
- Bonding is the connection of equipment so there is no potential voltage between equipment.
 - Both bonding and grounding must be used to assure a safe environment.

GROUNDING and **BONDING**

TYPICAL GROUNDING/BONDING CONNECTION



CALL IT WHAT YOU WANT!

- Grounding
- Earthing
- Protective earth conductor
- That green wire?

REASONS FOR GROUNDING

SAFETY

REDUCES ELECTRICAL SHOCK HAZARDS
CURRENT AMOUNTS AND EFFECTS

LIGHTNING

REDUCES STATIC BUILD UP

HELPS TO RETURN SURGES SAFELY TO GROUND.

RF BURNS AND SHOCK HAZARDS

RADIO FREQUENCY INJURY

It's The Law!

General requirements

- Grounding of electrical equipment
- Bonding of electrical equipment
- Bonding of electrically conductive materials and other equipment
- Effective ground fault current path

2017 NEC

National Electrical Code

- Enacted as law by NC legislators
- Insurance concerns.

Article 250

- · Covers grounding and bonding.
- Ensures safety and fire protection.

EQUIPMENT GROUNDING

Normally non-current-carrying conductive materials enclosing electrical equipment, or forming part of such equipment, *SHALL* be connected to earth so as to limit the voltage to ground on these materials.

Metal cases

- Radio
- Tuner
- Meters
- amplifiers

EQUIPMENT BONDING

Normally non-current-carrying conductive materials enclosing electrical conductors or equipment, or forming part of such equipment, *SHALL* be connected together and to the electrical supply source in a manner that establishes an effective ground-fault current path.

- Connect it all together
 - Everything listed in previous grounding slide!

CONDUCTIVE MATERIALS AND OTHER EQUIPMENT

Normally non-current-carrying electrically conductive materials that are likely to become energized *SHALL* be connected together and to the electrical supply source in a manner that establishes an effective ground-fault current path.

If it is conductive and <u>can become energized</u> then bond it and ground it!

EFFECTIVE GROUND-FAULT CURRENT PATH

Electrical equipment, wiring and other electrically conductive material likely to become energized **SHALL** be installed in a manner that creates a low impedance circuit facilitating the operation of the over current device.

- Grounding must allow for the correct operation of:
 - Circuit Breakers
 - Fuses
 - Circuit interrupters

ELECTRICAL SAFETY GROUNDING

#1 REASON FOR GROUNDING

- PERSONAL SAFETY
- SAFETY OF PERSONS VISITING
- FIRE SAFETY
- PROTECTION OF EQUIPMENT

YOUR STATION

DESIGN YOUR STATION

- Use best practices to install electrical
- Power equipment with low DC voltage
 - Less likely to cause serious injury
- Mitigate areas of high current
 - High current causes more serious injuries
- GROUNDING IS YOUR BEST PROTECTION!

AREAS OF CONCERN

OUTLETS

- Are outlets grounded per NEC?
- Are all ground prongs intact?





LIGHTNING PROTECTION

- LIGHTING SURGES AND STRIKES
 - CANNOT BE PREVENTED
- CAN BE DIVERTED TO GROUND
- CAN REDUCE THE AMOUNT OF CURRENT FLOWING THROUGH EQUIPMENT.
- MOST RADIO EQUIPMEN IS SOLID STATE
 - THE COMPONENTS OPERATE AT LOW VOLTAGE
 - HIGHER VOLTAGE FROM SURGES DAMAGE THEM BEYOND REPAIR.
 - YES IT IS A GAMBLE. INCREASE YOUR ODDS.



ANTENNA/TOWER


GROUNDING AT THE CONNECTION POINT

GROUND THE SHIELD AND ALL METALLIC PARTS
THAT DO NOT CONNECT TO THE CENTER
CONDUCTOR.

GROUND THE TOWER OR POLE AT THE BASE ON EACH LEG OR MULTIPLE TIMES.

- DRIVE 8' GROUND RODS
- BOND THEM TOGETHER WITH COPPER CONDUCTOR.

TOWER AND ENTRY GROUNDING







RF MANAGEMENT

- RADIO FREQUENCY VOLTAGE AND CURRENT CAN DISRUPT NORMAL OPERATION (RFI).
- "THERE IS NO RF GROUND"
 - EQUALIZE AUDIO AND RF THROUGHOUT YOUR STATION
 - BOND ALL CONDUCTIVE MATERIALS
 - BONDING DOES NOT ASSURE "0" AUDIO AND RF VOLTAGE BUT KEEPS IT THE SAME SO CURRENT WILL BE REDUCED.

REMEMBER!

- YOU CANNOT OVER GROUND!
- KEEP ALL EQUIPMENT BONDED TO REDUCE POTENTIAL VOLTAGE AND CURRENT.
- KEEP ALL GROUND CONDUCTORS AS SHORT AS POSSIBLE.
- ALL GROUNDING ELECTRODES MUST BE BONDED TOGETHER.

