



## MP5 TailHook Adapter Install Instructions:

### Tools required:

- 1 Metal Cutting Tool
- 1 Rubber/Soft mallet
- 1 Metal File (for burrs)
- 1 1/8 inch Metal Cutting Drill Bit.
- 1 1/8 x 3/4 inch roll pins (Included)

**NOTE:** This modification is geared to work only with an ATI 4 Position MP5 Stock. It has been test fitted before being shipped.

### Step 1: Removal of Butt Plate

1. Using your cutting tool, cut off the end butt plate exactly where the polymer starts. This must be very exact. The cutting disk will be up against the polymer - this will also assist in a straight cut.
2. Clean rails of any burrs with file.
3. Place adapter on rails- tap down with mallet. Make sure it goes all the way down- Should be somewhat of a tight fit.
4. Test the remaining 3 positions. It should lock on each one. If they do not you may have one rail out of alignment.
5. Once again, before you drill the PIN holes make sure the stock locks on the 2nd or 3rd position. Use the pilot holes to drill your holes.
6. 2 1/8" roll pins have been included. Use these to pin your adapter to the rails.

**NOTE:** Again because the modification is not being completed in-house we cannot guarantee success. However we have worked this out to make it as simple and as standard as possible. Please contact me if you have any questions.

**NOTE:** You will see pre-fitting marks on your adapter. This ensures quality control.