



APC TailHook Adapter Install Instructions:

Tools required:

- 1 T-10 Star Bit & Driver
- 1 Heat Source (Heat Gun or Small Torch)
- 1 Rubber/Soft mallet
- 1 Lock Tight (or some type of thread fastener)

Step 1: Removal of Butt Plate of B&T Stock

1. You must use a generous amount of heat on the T-10 screws in order to remove them from the rails. PLEASE take your time to make sure they can be removed without stripping. We have included 4 replacement screws in case this happens.
2. Clean rails and screws of old fastener.
3. Best if the B&T stock is not attached to the firearm. Align the adapter to the rails (rounded hump is the top) With the rubber mallet hammer the adapter into place. Once it stops sliding down it is in place.
4. Hole alignment - The Holes will NOT look aligned. This is normal. Apply screw fastener to screws- fasten each screw until it is flush **NOTE! Do NOT tighten down.** Doing so may strip the screws.



5. Test to ensure rail slides easy as it should.

NOTE: Just like the Stock Butt Plate, the adapter sits behind the last notch and so on collapsing the rails- it will have a Metal on Metal contact.