



B&T Stock TailHook Adapter Install

Instructions:

Tools required:

Cutting tool (Band Saw recommended)

Measuring tool (Caliper in MM recommend)

Drill & Drill Bit (7/32" it is IMPORTANT that this is in inches)

5 mm Hex wrench

Metal Flat File (optional but recommended)

NOTE: Cutting too much off of the stock can cause this to not fit correctly and will produce wiggle.

1. Cut off the Attachment nub from the stock- (this protrudes out about 5 mm from the stock towards the rear- this needs to be removed so the adapter can slide over it)
2. Cut off the bottom of the stock. Mark a straight line measured from the top to be 18 mm. That is how much should be left to allow the adapter to slid in. It is always better to leave more material than less.
3. Cut the very end of the stock 10mm worth. You should now have a 18mm x 14.10mm end piece

Fitting

1. File the area that had the Attachment nub, make sure it is flat/flush with the rest.
2. Try to slide the adapter onto the end. If it is giving resistance stop and file or cut as much needed.
3. Continue to file and fit until it slides in all the way.
4. Mark the hole on the stock and remove the adapter. Remove the adapter.
5. Drill the hole all the way through.
6. Fit the adapter back on and bolt the adapter to the stock with the provided Hex Nut. (it will self thread)