

Tech Smith DAS BOOT SB Converter

Install Instructions



Compatibility:

Any "B&T" style rubber end of an SB Tactical Brace, that has the same male end connector.

- * MP5
- * MP5K
- * APC 223/45/9



Items Needed to begin:

- * A very sharp knife
- * 2 mm Hex wrench
- * 3 mm Hex wrench



1. Remove the velcro strap from the rubber brace.
2. Pull the sides of the rubber away from each other (from the bottom of the brace).



3. With your very sharp knife, start to slit the inside rubber from the top to the bottom. (Picture for Top/Bottom reference.)



4. Pull the sides apart- like splitting a banana. Once started- peel it back and pull all the way down.

NOTE: This will ONLY work if you made a cut all the way down on the inside of the brace.



5. Install DAS BOOT by sliding it down the SB Brace spine. There are 2 tabs on the end of the spine that will line up and slip into the Tailhook adapter portion.

NOTE: Light tapping may be needed to fully fit it onto the spine. It will be flush and clip into the end.

6. Secure with the provided hex bolt, using a 2mm hex wrench. (until snug-do not over-tighten)



7. Install your Tailhook

8. Install back onto your favorite firearm.

NOTE:

On some spines after the rubber is removed 2 small round cylinders are present by the base (closest to the latch) These need to be removed before install of DAS BOOT. They are very small and remove with a little pressure of your sharp knife.