

Tech Smith Manufacturing LLC 2018

CZ 61 Install Sheet

Tools:

- ✳ Metal Cutting Tool (Grinder) or Dremel with Cutting disk
- ✳ Rubber Mallet

Cut the Factory Stock end off (3rd rib is the perfect location- but not standard- see picture)



NOTE:

After cutting the stock- the two wires will be independent and move freely.

NOTE:

Notice which end is up and down before you install.

Attach the adapter to the stock wire pieces

Using a rubber mallet, tap the stock down onto the adapter trying to keep it going evenly on both sides.

You are finished when it is flush with the adapter.

You are now finished and ready to install your Tailhook.