

## KPOS Scout Tailhook Adapter install

You will need to Cut off the Butt Pad and the Support beam of the Stock



You will then need to shave the bottom off enough for the adapter to slide on.

Do not remove too much as this will cause the adapter not to be stable.

You will need to drill a hole (use the adapter as a way to start the pilot hole).

BIT Size: 11/64

Stock Height/Removal Measurement: 15mm (0.60")

