

DROPKICK AXLE LOCK INSTALLATION INSTRUCTIONS 2009+ HARLEY-DAVIDSON TOURING MODELS

Introduction

Thank you for your purchase of your new DropKick Axle Locks.

1. Place bike on center jack.
2. Remove saddlebags
3. Raise jack until the pressure is off the shocks
4. Remove left side shock
5. Install the included spacer on the top shock mount, lightly snug the top bolt
6. Install the axle lock over the axle and align the slot for the shock bolt & install bolt
7. Remove axle clip from right side disregard axle clip it's no longer needed
8. Remove right side shock
9. Install the included spacer on the top shock mount, lightly snug the top bolt
10. Install the axle lock over the axle and align the slot for the shock bolt & install bolt
11. Torque shock bolts to factory specs.

Sometimes it may be necessary to adjust the nut location for installation. Be sure to tighten the axle to move nut location.

- DropKick Customs products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur. To find the latest information. Please contact DropKick Customs if you have any questions regarding the contents in this document.
- DropKick Customs shall not be held liable for any consequential or incidental damages resulting from the failure of a DropKick Customs part. Epic Moto Co shall have no obligation if a part becomes defective as a result of improper installation or abuse.