

MILWAUKEE 8 IGNITION RELOCATION BRACKET INSTALLATION INSTRUCTIONS HARLEY-DAVIDSON MILWAUKEE 8 MODELS

Introduction

Thank you for your purchase of your new DropKick Customs product.

1. Remove the Stock OEM Horn and mount from motor.
 2. Remove the motor strap bracket for horn mount
 3. Install the Face Plate to the Face Plate Mount using the (2) 10-32x2.25" bolts see image
 4. Using the (4) 8-32x 3/8" bolts mount your stock ignition with wiring connected to the DropKick Customs face plate. See Image
 5. Install the Ignition Assembly using the (2) 3/8-16x 1-1/4" bolts to the motor using the same holes the factory horn strap was located. Keep your fuel line on top of the face plate bracket.
 6. Use Blue Loctite on all hardware. Sometimes it may be necessary to adjust the nut location for installation. Be sure to tighten the axle to move nut location.
- DropKick Customs products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur. To find the latest information. Please contact DropKick Customs if you have any questions regarding the contents in this document.
 - DropKick Customs shall not be held liable for any consequential or incidental damages resulting from the failure of a DropKick Customs part. DropKick Customs shall have no obligation if a part becomes defective as a result of improper installation or abuse.

Hardware Includes:

- (2) 10-32x2.25" socket cap bolts
- (2) 3/8-16x1-1/4" flat head bolts
- (4) 8-32x3/8" socket cap bolts



Face Plate



Face Plate Mount



Face Plate Installed to Mount

