Free Camera Inspection

Inspect the existing pipes for any cracks, corrosion, or roots using a drain camera. Estimate and/or Quote will be provided.





Install Clean-Outs

(If needed.)

**Two access points are needed to insert/place liner.

Clean and DeScale Line(s)

Debris, roots, and corrosion are then removed from the pipes.

Line will be flushed with water to remove any debris.

Pre and Post Cleaning Videos will be taken.









Take Measurement-Prep

Measurement (length and Diameter) taken with camera.

Tie-Ins will be marked for gapping.

Mix Epoxy; Prepare Liner

Find a good shaded location to mix epoxy.

Remove tie-in section, to leave open. String line. 2 pull points.





Install Liner; Place and Wait

IPT liner is pulled into the pipe and cures in place.

Using Camera, liner will be placed on previous marks taken.

Air up bladder that helps keep shape while curing.

Curing time 3-5hrs based on mix and



Completion

A final inspection with camera is performed for quality assurance.

After lining video will be taken.

20yr warranty will be provided.

All videos will be provided to customer.





