

- INSTALLATION STEPS**
1. INSTALL RN389 LEVEL
 2. ASSEMBLE SIDELIGHT
 3. INSTALL SIDELIGHT
 4. INSTALL RN303 PARTS
 5. SCREW RN303 / RN352 TO RN389
 6. SCREW RN303 TO DRYWALL
 7. SET DOOR OPENING WIDTH
 8. SCREW RN352 TO DRYWALL
 9. VERIFY PLUMB/SQUARE OF FRAME
 10. ANCHOR RN350/RR420 TO FLOOR
 11. LOAD ROLLERS INTO RN456 TRACK
 12. INSTALL RN456 TRACK
 13. NUT/BOLT ASSEMBLY RN456 TO RN389
 14. INSTALL RN467
 15. INSTALL RA406 CLIP AT FLOOR
 16. INSTALL RN468 SNAP COVER
 17. INSTALL TRIM COVERS AFTER GLASS IS INSTALLED
 18. INSTALL GUIDE PIN
 19. HANG DOOR

