

INSTALLATION INSTRUCTIONS FOR IMCO-NV DRIVE SHOWERS

NOTE: DRAWING SHOWS PROPER LOCATION FOR A R.H. ROTATING PROPLER, FOR A L.H. ROTATING PROPLER SWITCH SIDES.

- A. LOCATE PICKUP ON CAVITATION PLATE PER DRAWING AND DRILL THE 7/16" HOLE FIRST, INSTALL PICKUP AND DRILL THE 1/4" HOLE, INSTALL 1/4" NUT AND BOLT PROVIDED
- B. REMOVE THE TOP TWO REAR BOLTS OR NUTS (THIS WILL DEPEND ON WHICH STERN DRIVE YOU HAVE) INSTALL NEW STUDS OR NUTS AND TIGHTEN TO 35 FT LBS, INSTALL DRIVE SHOWER USING THE 3/8" BUTTON BOLTS TIGHTEN TO 15 FT LBS.

CAUTION: CHECK FOR CLEARANCE BEFORE TRIMMING DRIVE ALL THE WAY UP, ADJUST ACCORDINGLY

