

## INSTALLATION INSTRUCTIONS FOR IMCO-NV TRS WING PLATE

- A. REMOVE BOLTS ONLY FROM THE REAR ALUMINUM COVER PLATE (DO NOT REMOVE COVER PLATE)
- B. INSTALL STUDS PROVIDED, TORQUE @ 35 FT LBS
- C. INSTALL WING PLATE PER DRAWING, TORQUE NUTS @ 30 FT LBS
- D. INSTALL CLEVIS STUDS PER DRAWING, TORQUE 3/4" NUT(S) @ 120 FT LBS

