

INSTALLATION INSTRUCTIONS FOR IMCO-NV BRAVO X-BOX

- A. USE THE X-BOX AS YOUR TEMPLATE AND DRILL 8ea 7/16" HOLES
TRACE AND CUT OUT THE ENTIRE CENTER OVAL SHAPE HOLE, INSTALL X-BOX AND MOTOR
BRACKET FOR SEALING X-BOX TO TRANSOM USE 100% SILICONE

