

Teryx Reverse Light Pod Kit



The hole on the passenger side frame rail where the wiring harness retainer is located will need to be enlarged

The wiring harness will need to be relocated above the middle cross bar. Zip tie if desired.

The driver side frame rail will need an identical hole drilled.

Use the short bolt provided and thread directly into the light.

Wiring the new harness into the black connector under the bed is easy,

Unplug the connector and remove the white retainer.

The new red wire will go under the existing black wire.

The new black wire will go under the existing blue wire.

I have provided the original brackets; they are not needed. If you choose to mount the light in a different location, they could be useful.

Any other questions feel free to contact

Brute Performance

8609193094