



Remove two bolts to reveal headlight housing. FIG: 1

Remove the adjusting screw assembly from the bottom of the factory light. It will not be reused.

Remove the two 8mm bolts that hold on the headlight. They will not be reused. Save the washers

Unplug the factory light and remove.

Install the provided longer 8mm bolt with the factory washer thru the mounting hole then install the provided spacer with the recess towards the grommet and the flat side towards the light as shown. FIG:2

Install the new led headlight assembly with provided hardware level with the housing as shown. FIG: 3

Reinstall the headlight bucket and align the light so it sits tight to the housing as shown. FIG: 4

Recheck alignment; then tighten all the bolts and screws.

PLEASE INSTALL BOLT HEADLIGHTS before cycling the low and high function. Or disconnect the factory halogen assembly to test the first new light installed

The electronics and plugs are waterproof/shockproof.

Enjoy! I will provide a 6 month warranty with these lights. For WHATEVER reason they stop working I will replace whatever is wrong. Purchase date:

Brute Performance

8609193094