

TERYX Reverse light install instructions

Wiring the new harness into the black connector under the bed is easy,

Unplug the connector and remove the white retainer.

Remove the black dummy plugs

The new red wire will go under the existing black wire.

The new black wire will go under the existing blue wire

The pins will click in once fully seated

Run your wires red to red and black to black from your lights



