





Wildcat XX Seat Riser Instructions

- 1. Remove driver seat and flip upside down. Remove the two rubber grommets and remove the latch assembly.
- 2. Install the outer seat riser first with the bolts provided. Tighten with ½ inch wrench. Locktite is recommended.
- 3. Reinstall seat grommets on top of the new spacer.
- 4. Install the inner seat risers with bolts provided. Order as follows, bolt, thick washer seat latch, spacer, seat frame, thin washer, locknut. Then tighten.
- 5. Put seat back in machine and enjoy your new comfort.