

Thank you for purchasing our KRX door assist kit.

When completed your installed kit will look as pictured

Tools required

¼" drill bit

5/16 tap

10mm socket

13mm socket and wrench



First

measure 1" from the center of the floorboard screw

Drill and tap a hole to accept the short ball stud. Install stud





Second

Measure 8.5 inches from the lower door bar

Drill and tap the door bar all the way thru

Install the long stud with the jam nut on to as shown

