

KRX 1000 FAN SHROUD ASSEMBLY

Remove the hood, grille and inner front plastics to access the radiator

Remove the 4 radiator bolts top and bottom

Remove the coolant tank bolt from the driver side, move tank out of the way

If a wiper kit is installed remove the water tank from the passenger side

Unhook the OEM fan shroud from the 4 black grommets

Remove the OEM fan assembly up from the driver side being careful not to damage the radiator fins.

It's a tight fit but it will go



Remove the 4 spacers and the 4 OEM rubber grommets.

Install the Provided Grommets in the same location.

Reinstall the OEM spacers as shown.

Spacers go in the opposite way of factory



Install the new fan assembly from the driver side as shown



Align the new fan assembly so no edges are rubbing the radiator

Install the provided washer



Then install the OEM bolts



RE assemble plastics and grille.

In the fuse box behind the driver seat replace the stock 15 amp breaker with the provided 20 amp breaker



The new fan assembly will draw more amps than the stock fan.

It is recommended but not required to have an alternator installed on the machine
If no alternator is installed be aware of voltage when using light bars, heaters or stereos.