

H2 Tie Rods

Inner Joint 1.5" of Thread into the Bar

Outer Joint 1.25" of Thread into the Bar

Red Loctite on Inner joint threads to the Steering Rack

The small end of the boot goes on the recess of the bar.

Assemble inner joint to the Bar.

Assemble the assembly to the steering rack.

Pull boot over the bar, some oil will help.

Install outer Joint.