

**THE FOLLOWING APPLIES TO 2009 & LATER SOFTAIL CLASSICS AND
CROSS BONES ONLY**



1. Place the Heelguard on the bottom of the footboard approximately 3 1/2 inches from the rear of the footboard, trace the outline and mark the holes to be drilled.



2. Drill two 1/4 inch holes, place the supplied bolts through the holes and then place the two spacers on the bolts.



3. With the supplied bolts and spacers in place, install the Heelguard on the bottom of the board with spacers in between the Heelguard and the footboard and secure with supplied nuts.



4. The finished Heelguard attached to the footboard (bottom of the footboard looking from front to rear).



4. The finished Heelguard attached to the footboard.



STOP BURNING RUBBER!