

## 8100RL INSTALLATION INSTRUCTIONS FOR:

Mounts on Harley Davidson Part# 50459-06 Passenger Footboard mount for Heritage SofTail and Other SofTail models

**Photo #1** – Grind areas as shown so clamp will fit. Dime will be used for a spacer.



Photo #2 - Underside View after grinding.



**Photo #3** – Final Underside view with heel guard clamped to mounting bracket. Note the dime is being used for a spacer.



**Photo #4** – Final Top View

