

Bedside Covers Instructions

1. Identify the front of the Passenger Side Bedside Cover (reference picture below).
2. Install Passenger Side Bedside Cover using the supplied hardware along with a 3/16" Hex Key and ½" wrench/socket.
3. Repeat on Driver Side.
4. Enjoy your Disruptive Restomods Bedside Covers.



Front (Passenger Side)