

Side Mirror Installation Instructions

1. (if applicable) Remove old mirror from vehicle.
2. Inspect the mounting holes for damage and if no damage then test fit the supplied #10-24 bolts by screwing them into the threaded holes in the vehicle. If there is any resistance then STOP and do either of the following
 - a) use a #10-24 tap and clear the threads of any debris or small imperfections (this tap should easily screw into the hole if not then it is **not** the correct thread size and do one of the following)
 - i) install the provided Rivet nuts by using a 19/64" drill bit and drilling thru the panel. Then use a Rivet Nut Installation tool (not included) to compress the nut.
 - ii) drill a 11/64" thru hole and use a #10-24 locking nut (not provide) on the back side of the door panel.
3. Install the Side Mirror Gasket with the edges facing up which go around the edges of the bottom of the Mirror. Insert bolts and tighten using a 5/32" allen key. (The reason a socket head bolt is used is to enable more torque for a tighter mirror fit to the door panel and to deter theft)
4. Adjust mirror (please note: these are alot tighter then other mirrors [designed that way] so you may need to hold the vertical section of mirror while being adjusted).
5. Enjoy your Disruptive Restomods Side Mirror.