XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM

COPYRIGHT Factory Works 8/10/04

unt Drill Jig This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK

XXXNT PRO REAR TOWER Suspension arm

Shock mounting Instructions PT# 2194

SECOND

COPYRIGHT Factory Works 8/10/04

#### XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM

COPYRIGHT Factory Works 8/10/04

#### XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194

OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM.



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM

COPYRIGHT Factory Works 8/10/04

### XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194




This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM

#### XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM.

# XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM

COPYRIGHT Factory Works 8/10/04

## XXXNT PRO REAR TOWER Suspension arm Shock mounting Instructions PT# 2194



This tower requires drilling and cutting of the stock rear suspension arm. Start by mounting the drill jig to one of the arms as pictured then, using the supplied drill bit to drill a hole though the arm. The same drill jig will fit both arms by flipping it around. Now cut off the stock shock mounting block with a hobby saw or you can use a heck saw, cut slow to make it nice, then clean up with sand paper as desired. Getting the shock closer to the wheel Improving it's control over the wheel. Less wheel bouncing and lets you use softer springs and lower weight oils in your shocks. USE THE SUPPLIED WHITE NYLON NUT AS A SPACER TO SPACE THE SHOCK OUT FROM THE ARM FOR CORRECT SHOCK ANGLE TO THE ARM.

COPYRIGHT Factory Works 8/10/04