

11183 1989 Stealth car Ball Bearing Steering Kit

Start by trimming the post off either arm. You will end up with a flat arm for this application. You will need to take a bit of material off the servo block, see pic attached. Just a notch to keep it from rubbing the idler. Install a bearing on each side of that arm, and also the idler arm. Install the rack bar as shown facing rearwards with a shim between the bellcrank and drag link. Using the flat head screw tighten until snug, then back off until free. Install the steering ball joint onto the rack using the included thin nuts, and a ball joint into the input side of the bellcrank.

Next, install a #8 thin washer and the steering post onto the kit screws. Do not overtighten as the plastic will spread. Just snug. Drop the bellcrank and drag link assembly onto the posts and secure with the original locknuts or the included plastic nuts depending on your personal preference.

Now you can set your toe and check for proper throw. That's it!

