

## VintageRC Shorty Lipo holder

- 11) Remove existing battery holder
- 12) Secure posts to the hockey sticks with flat head screws
- 13) Attach hockey sticks to chassis using flat head screws and lock nuts
- 14) Orient the upper tray to suit your needs, and attach to posts using 3x8mm button head screws
- 15) Use the o-ring to secure the battery

