



Natural Action Technologies®

Structured Water Unit

## Installation Instructions for Shower Unit (Compact)

1. Remove existing showerhead. Clean the shower pipe threads with an old toothbrush or rag to remove debris. Apply a light coat of soap to the pipe threads. The unit may be threaded easily onto a 1/2" pipe.

2. Install the shower unit to the 1/2' shower pipe in wall. Be aware of possible cross threading. (The unit should start on the pipe threads easily when it is lined up correctly. Be patient here and thread gently. If cross threading should occur, a 1/2' tap, obtained through a hardware store, can be used to rethread the unit.)

3. Next, thread the showerhead onto the shower unit.

4. Tighten the shower unit to the shower pipe, and the showerhead to the shower unit sufficiently to prevent leakage. Over tightening may make it difficult to remove, or cause damage to the threads.

**Cleaning:** Clean by soaking the unit in a bath of water and apple cider vinegar, warm soapy water, or by running thru the dishwasher. Baking soda works well also, just put a teaspoon into your unit and add a 1/2 cup of vinegar. Rinse thoroughly.

**Storing:** The Shower Unit can be drained and stored in either direction, i.e., spout up or spout down. Avoid leaving this unit in freezing temperatures with residual water inside as impaired function may result.

Avoid dropping this unit as it may result in impaired function.

*The Natural Action Technologies limited lifetime warranty coverage of (10) years covers manufacture defects or quality issues. It is also accompanied by a 90-day customer satisfaction guarantee from the date of delivery. The warranty does not include misuse, abuse, sunlight damage, improper installation, freeze damage, natural disaster or blemishes from the manufacturing process.*

Structured Water Products

1519 S. Koch Ranch Road Cornville AZ 86325

541--728-1766

[SructuredWaterProducts.com](http://SructuredWaterProducts.com)