



Easily measure tuft length with convenient Wira apparatus

Accessories for manually checking carpet tuft length.

Test Method

The apparatus consists of a Tuft Length Block, a Perspex block with V-shape grooves, glass rods and metal ruler.

At least 20 tufts are removed from the sample. The individual tufts are straightened and placed in the appropriate groove. The glass rod is placed over the tuft and the length is measured using the ruler.

Key Features

- ✓ *Quick and easy to use*
- ✓ *Provides instant readings*
- ✓ *Can be used in the lab or in production facility*
- ✓ *No power required*

Conforms to: BS 4223:1989

Order Code: TLM:001

