



“DO NOT OVERTAKE TURNING VEHICLE STICKER”

This sign ensures that your van is compliant with Australian regulations and helps to raise awareness for drivers behind you.

Please note that if your vehicle (meaning the towing vehicle together with the trailer) needs to straddle lanes or turn from an adjacent lane to turn left or right at intersections and it is 7.5 meters long or longer, you must display a “DO NOT OVERTAKE TURNING VEHICLE SIGN”. Not doing so is illegal.

Please remember that other drivers are prepared for trucks to use multiple lanes when turning, they may not necessarily be prepared for caravans doing these manoeuvres. So whenever using multiple lanes to conduct a turn, please exercise caution, and be aware of other drivers.

When mounting the signs on the rear of the caravan, please ensure that the following measurements are observed.

The sign should be:

On the left side facing the rear of the vehicle:

**DO NOT OVERTAKE
TURNING VEHICLE**

- A. No higher than 2,000mm from the ground (preferred is 1500mm)
- B. No lower than 400mm from the ground
- C. No further in than 500mm from the left side of the van to the left edge of the sticker.

A tip for applying the sticker:

Wet the area with a mild mix of water and washing up detergent, apply the sticker to the damp surface as this gives you a little bit of movement. Then once in place correctly, squeeze out all the water and flatten the sticker in the ripples etc. Leave it to dry. If you try and apply dry it is a VERY sticky sticker and once it touches it is very hard to correct. Once on dry it, it will not come off easily.