



## Luv Subbin's Winterization Checklist

- Flush black water tank until effluent is clear.
- Open fresh water tank drain valve. Open low point drain petcocks. Drain water.
- Open black and grey valves with pan underneath.
- Use jack to raise and lower RV to ensure all water is drained out.
- Close all valves except the low drain petcocks. Leave them open for system blow out.
- Open hot water heater's pressure relief valve and drain plug. Drain all water.
- Flush hot water tank multiple times.
- Lightly replace hot water tank drain plug.
- Install blow out fitting at city water connection.
- Open kitchen faucet.
- Hook up bicycle pump (or air compressor set to 60 psi) and start blowing water out.
- Cycle kitchen faucet to both hot and cold until no water comes out.
- Turn on hot then cold water at bathroom sink. Leave on until no water comes out.
- Flush toilet and leave open until no water comes out.
- Open toilet sprayer until no water comes out.
- Open outlet pipe to water pump and ensure no water comes out when blowing air.
- Close low point drain petcocks.
- Close hot and cold inline valves to water heater.
- Open bypass valve.
- Unscrew inlet pipe to water heater and screw on flexible antifreeze hose.
- Dispense RV/Marine potable antifreeze into a suitable container.
- Insert hose into antifreeze and pressurize system by turning water pump to "On".
- Cycle both hot and cold settings on kitchen and bathroom faucets until only pink fluid is observed.
- Flush toilet until only pink fluid is observed.
- Run toilet sprayer until only pink fluid is observed.
- Remove and store faucets.
- Ensure tires are inflated to sidewall pressure.
- Remove Tire Pressure Monitoring caps.
- Cover tires with UV covers.
- Remove battery and store inside heated garage. Check electrolyte levels. Check and record initial voltage. Charge once per month.
- Remove all items from exterior compartment.
- Photograph all compartments for spring commissioning.
- Remove and store all interior items.
- Clean refrigerator. Prop open fridge and freezer doors for ventilation.
- Set out Damp Rid.
- Set out Mouse deterrents.
- Start counting the days til Spring!