

Dumb Stick Installation Instructions

Disclaimer:

- The Dumb Stick is designed to carry tongue weight loads of up to 30 lbs. Do not exceed 35 lbs tongue weight load.
 - Do not use the dumb Stick to tow any human beings in any device.
- 1) Look at your seat post and measure the height of your seat post from the bottom of the seat connection to the top of the bike frame before you detach the seat post from the bicycle frame.
 - 2) Unbolt the seat post from the bicycle frame and remove from bike frame.
 - 3) Slide the seat post through the Dumb Stick while making sure the logo lettering is right side up.
 - 4) If the spacer is needed to keep the dumb stick elevated from the back tire, slide onto the seat post.
 - 5) Replace the seat post into the bike frame and tighten it back up to the desired height.
 - 6) With the Dumb Stick pointing straight back toward the back of the bicycle. Make sure that the Dumb Stick sits high enough so it doesn't rub against the back bicycle
 - 7) Clip the item to be towed ie: kayak, canoe, and wagon. to the spring clip on the end of the Dumb Stick.
 - 8) You are now ready to tow your item with caution. Make sure that no part of the device being tailored, nor any ropes, towels, or ties, makes contact with the rear wheel of the bicycle!