



## **Foot Piece & PINs Installation Instructions**

### **LengthBoard Foot Piece Installation**

1. Insert white pins into holes at head-end of slot.
2. Push lightly and slide back.

**To remove foot piece: Slide foot piece to holes and lift up.**

**\*\*White pins on foot piece can be adjusted if necessary. Tap pins lightly with small hammer until foot piece slides smoothly without side to side movement.**

### **LengthBoard pins Installation**

1. Place foot piece bottom side up on a hard elevated surface leaving space under pin area.
2. Place pins in holes, insuring pins are vertically straight. Carefully hammer pins with small hammer.
3. Adjust pins up or down to eliminate slop and allow foot piece to slide smoothly without side to side movement.

### **Threaded pin and Locking knob Installation**

Insert threaded pin up through board slot, through foot piece and screw on knob.

**NOTE: Knob does not need to be completely removed for proper use.**