



POLYROD INSTALLATION INSTRUCTIONS

Stone Vos double stitches our seams, so we can't install the new plastic polyrod/rope/gimp at the same time. To assist you with the polyrod, we lay a string in the pocket and staple it on each end. Then we label the coach rail string with a tag that coincides with a label on the polyrod.

Steps to Install polyrod:

1. Remove the staple on **ONE** of the ends only.
2. Take the polyrod with the matching label.
3. Wrap the string in a spiral around the polyrod for 8 – 10 inches and then wrap electrical tape around the string & polyrod and squeeze it on really good. You don't want the tape to come off as you are pushing the polyrod through the pocket. **
4. Remove the staple at the other end.
5. Have someone pull the string as someone is pushing the polyrod into the pocket.
6. Once the polyrod is installed in the pocket, cut the polyrod where the electrical tape is but leave 6" on each end for the coach rail and 1" on each end for the roller tube rail.
7. Now you are ready to install your new awning and/or topper.

If the string comes off the polyrod while installing it, you will need to reinstall it using a Fish Tape. Wrap the string on the fish tape, repeat step 3 and then fish the string through the pocket. This way is very time consuming.

If you have any questions or problems, please feel free to give us a call at 352-942-0224.



