



PowerPass Slim

Footprint:

20" Wide x
36" Deep

Side or Rear
Access Required

Breakers:

Square D R Frame
Up to 2000A
3 Pole

Optional SKRU or
Kirk Key



PowerPass Core

Footprint:

36" Wide x
36" Deep

Front Access Only
Required

**Efficient
Installation:**

Hinged panel for
easy cable access

Breakers:

Square D R Frame
Up to 2000A
3 Pole

Optional SKRU or
Kirk Key



PowerPass Pro

Footprint:

30" Wide x
36" Deep

Side or Rear
Access Required

Side Car available
for Front Access
Only

Breakers:

Square D MTZ
Up to 2000A
4 Pole

Optional SKRU
or Kirk Key

