



NOTES:

- 1: EACH ROW MARKER WILL HAVE THE SECTION AND ROW ENGRAVED ON EACH MARKER.
- 2: SECURE THE END OF A TAPE MEASURE TO THE ROW MARKER AND PULL THE TAPE OUT TO THE CORRESPONDING ROW MARKER AT THE OTHER END. THEN GO BACK TO THE START OF THE TAPE AND COUNT OFF EVERY 4'-0" TILL YOU REACH THE BURIAL PLOT YOU ARE SEARCHING FOR.
- 3: THE ROW MARKERS ARE LOCATED 1'-6" OFF THE HEAD OF THE BURIAL PLOT SO THAT THE GRAVEDIGGER WILL KNOW EXACTLY WHERE TO DIG AND WILL ALSO LEAVE A PORTION OF THE BURIAL PLOT UNDISTURBED FOR THE MONUMENT TO BE PLACED.
- 4: FOR BURIAL PLOTS THAT ARE LOCATED BETWEEN EXISTING BURIALS PULL THE TAPE FROM THE CENTER OF ONE MONUMENT TO THE CENTER OF THE OTHER MONUMENT THEN LOCATE THE NEW BURIAL PLOTS MAKING SURE NOT TO ENCROACH ON THE EXISTING BURIALS AND ALLOWING ENOUGH SPACE FOR ALL THE AVAILABLE PLOTS.