

Wishbone nut & bolt kit S2 Elise/Exige & VX220 – Fitting guide

(WSH-BLT-SET; RR-WSH –BLT-SET & FR-WSH-BLT-SET)

Bolt positions:-

Front Top Wishbone

Front 1x M10x80mm (2 Total)

Rear 1x M10x75mm (2 Total)

Front Lower Wishbone

Front 1x M10x85mm

Rear 1x M10x85mm (4 Total)

Rear Top Wishbone

2x M10x60mm (4 Total)

Rear Lower Wishbone

Front 1x M10x65mm (2 Total) FIT TAB WASHERS

Rear 1x M10x75mm (2 Total) (standard supplied i.e. no cross brace or toe link kit)

Rear bolt alternatives:

Rear 1 x M10x120 (2 Total) (cross brace) - Not supplied

Rear 1 x M10x110 (2 Total) (typical toe link kit) - Not supplied

Recommended tools:-

17mm spanner and 17mm socket set (flexible joints and extensions for the foot well bolts)

Torque wrench

Alignment tool especially with the front castor washers can be very useful:

<https://jordanengineering.co.uk/products/ols/products/castor-shim-alignment-tool>

Tips and Advice:-

Torque up the bolts with the suspension arms raised to horizontal in the normal sat position i.e. not hanging down so the rubber bushes are fixed in the correct position.

Jordan Engineering

t: 07790 406 334

e: chris.jordan@jordanengineering.co.uk

w: <https://jordanengineering.co.uk>

Jordan Engineering

t: 07790 406 334

e: chris.jordan@jordanengineering.co.uk

w: <https://jordanengineering.co.uk>