

Jacking point lift puck kit fitting (JCK-PUK-KIT)

1. Remove rear diffuser, jack up rear of car and remove under tray in the usual way. Always use proper support such as axle stands when working under a vehicle.
2. Remove end bolt of cross member/shear panel.



3. Bolt on one of the pucks orientated with the centre of the puck towards the centre of the car along the lateral support (in-line with the other bolts) with the nut, bolt and washer supplied.



4. Repeat on the opposite side and take a measurement from the under tray fixing or similar to the centre of the puck (this is to be able to get the sticker in the correct position). In my case it was approx. 93mm.



5. Put your under tray back on. Clean, de-grease and dry the area well, where the stickers will go. It's recommend to measure and mark with indelible marker the sticker centre position and then apply the sticker. If the sticker comes off at least you still know the lift point - perhaps even draw around the sticker.

