



NOTE 1: ALL UNUSED PINS ON THE MIXER MUST BE SOLDERED TO GROUND.

NOTE 2: REPLACE JUMPER WITH A 33 Pf CAPACITOR TO BLOCK DC OFFSET FROM OSCILLATOR.