

DOOR BUSHING INSTALLATION GUIDE
PRODUCT: CUSTOM DOOR BUSHINGS
TOOLS REQUIRED:

FITTING BOLTS

SCREWDRIVER OR RATCHET

SILICONE SPRAY (OPTIONAL)

FINE-GRADE SANDPAPER (OPTIONAL)

STEP-BY-STEP INSTRUCTIONS

REMOVE THE ORIGINAL BUSHING

UNSCREW AND TAKE OUT THE FACTORY DOOR BUSHING FROM THE DOOR FRAME.

LINE UP THE NEW BUSHING

POSITION THE NEW BUSHING IN PLACE USING THE ORIGINAL MOUNTING HOLES.

INSERT YOUR FITTING BOLTS THROUGH THE BUSHING – IT WILL BE A TIGHT FIT. THIS HELPS HOLD THE BUSHING IN PLACE DURING ALIGNMENT.

PRE-FIT THE BUSHING (DO NOT FULLY TIGHTEN)

LIGHTLY SCREW THE BOLTS IN, JUST ENOUGH TO ALLOW SOME MOVEMENT.

REFERENCE THE IMAGE BELOW FOR THE CORRECT FITTING DIRECTION:

CLOSE THE DOOR GENTLY

WITH THE BUSHING LOOSELY IN PLACE, CLOSE THE DOOR SLOWLY.

THIS WILL ALLOW THE BUSHINGS TO SELF-ALIGN TO THE OPTIMAL POSITION.

FINAL TIGHTENING

OPEN THE DOOR AND CAREFULLY TIGHTEN THE BOLTS UNTIL THE BUSHING IS SNUG.

AVOID OVER-TIGHTENING – THEY SHOULD BE FIRM BUT NOT CRUSHED.

ADJUSTMENT TIPS

IF THE DOOR FEELS TOO TIGHT TO CLOSE:

TRY A SMALL AMOUNT OF CLEAR SILICONE LUBRICANT, OR

USE FINE SANDPAPER TO SHAVE DOWN CONTACT POINTS SLIGHTLY.

**IT'S NORMAL FOR THE DOOR TO FEEL A BIT STIFFER AT FIRST.
IT WILL EASE WITH REGULAR USE OVER TIME.**



Please do not over tighten