

NA/NB MAZDA MX-5 VENT TRIM INSTALLATION MANUAL
PRODUCT NAME: NA/NB REPLACEMENT VENT TRIM
COMPATIBILITY: MAZDA MX-5 NA (1989-1997) / NB (1998-2005)
TOOLS NEEDED: SMALL FLATHEAD SCREWDRIVER
SKILL LEVEL: EASY
ESTIMATED TIME: 5-10 MINUTES



WHAT'S INCLUDED

1X CUSTOM VENT TRIM (FRONT)

1X REAR VENT HOUSING (OEM REUSED)

VIDEO GUIDE

SCAN THE QR CODE TO WATCH THE HOW TO REMOVE BALL VIDEO



INSTALLATION STEPS

REMOVE THE ORIGINAL VENT BALL

CAREFULLY PULL OUT THE ORIGINAL VENT BALL FROM THE DASH.

REFERENCE THE VIDEO ABOVE IF NEEDED.

SEPARATE THE VENT HOUSING

USE A FLATHEAD SCREWDRIVER TO CAREFULLY SPLIT THE FRONT AND BACK VENT HOUSING.

WORK AROUND THE EDGE TO POP THE CLIPS APART WITHOUT BREAKING THEM.

INSTALL NEW VENT TRIM

LINE UP THE NEW FRONT TRIM WITH THE REAR HOUSING.

PUSH THE PARTS TOGETHER FIRMLY UNTIL YOU HEAR THEM CLICK.

REINSERT INTO DASH

PUSH THE COMPLETE VENT ASSEMBLY BACK INTO ITS ORIGINAL SLOT IN THE DASHBOARD.

