



VENT TRIM REPLACEMENT INSTALLATION MANUAL
PRODUCT NAME: CUSTOM VENT TRIM REPLACEMENT
COMPATIBLE WITH: VEHICLE-SPECIFIC DASHBOARD (REFER TO PRODUCT LISTING)
SKILL LEVEL: MODERATE
TOOLS REQUIRED:

PHILLIPS SCREWDRIVER

SMALL FLATHEAD SCREWDRIVER

OPTIONAL: PLASTIC TRIM REMOVAL TOOLS



INSTALLATION INSTRUCTIONS

STEP 1: REMOVE DASHBOARD TRIM

CAREFULLY REMOVE THE DASHBOARD TRIM TO ACCESS THE AIR VENT ASSEMBLY.

**FOR VISUAL GUIDANCE, PLEASE WATCH THIS SHORT TUTORIAL VIDEO:
SCAN THE QR**



USE TRIM REMOVAL TOOLS OR GENTLY PULL BY HAND TO AVOID DAMAGE.

STEP 2: REMOVE THE ORIGINAL VENT HOLDER

LOCATE AND REMOVE THE TWO SCREWS THAT HOLD THE FACTORY VENT ASSEMBLY IN PLACE.

CAREFULLY SLIDE OUT THE VENT ASSEMBLY.

STEP 3: SEPARATE FRONT AND REAR VENT HALVES

IDENTIFY THE SMALL PLASTIC CLIPS AROUND THE EDGE OF THE VENT.

USE A SMALL FLATHEAD SCREWDRIVER TO PRY EACH CLIP APART, WORKING AROUND THE PERIMETER.

GENTLY SEPARATE THE FRONT TRIM PIECE FROM THE BACK HOUSING.

STEP 4: INSTALL YOUR NEW VENT TRIM

ALIGN THE NEW FRONT TRIM PIECE WITH THE REAR HOUSING.

FIRMLY PRESS THE PIECES TOGETHER UNTIL ALL CLIPS SNAP INTO PLACE.

DOUBLE-CHECK ALL CLIPS ARE SECURE AND FLUSH.

STEP 5: REINSTALL ASSEMBLY

REINSERT THE COMPLETED VENT ASSEMBLY INTO THE DASHBOARD.

USE THE ORIGINAL SCREWS TO SECURE IT IN PLACE.

SNAP THE DASHBOARD TRIM BACK ON.

