

Valkyrie Carbs and Custom



Thanks for purchasing our products.

Installation Instructions for The SIZE MATTERS Emblems.

NOTE: The 3M tape is meant to be essentially permanent, so make sure you have the emblem where you want it. If you need to remove one, you can use fine dental floss and saw through the foam to cut it off. Goo Gone will remove the glue. You can buy new 3M tape to reinstall the emblem.

To get it mounted where you want it:

NOTE: The peak of the "A" is the middle of the emblem.

Method #1

1. Place a strip of painter's tape just below where you want the emblem.
2. Mark it with a pen for centering, aligning, leveling the emblem.
3. Use one of the included alcohol prep pads to clean the mounting surface.
4. Let it dry for a few seconds.
5. Remove the backing tape on one emblem.
6. Align the emblem with your marks and place it down.
7. Remove the painter's tape.
8. Repeat for the other emblem.

Method #2

Use a Sharpie marker to draw an alignment line on the chrome. After placement, remove the Sharpie line with alcohol.

Method #3

If you are one to live dangerously, just wing it. Eyeball it and stick it on. In this case, you may want to review the note about it being essentially permanent, and how to remove it!

If you have any questions, or a problem with your product, contact me. I will do everything I can to resolve it to your satisfaction.

Dave

mooskee@valkyriecarbsandcustom.com

www.valkyriecarbsandcustom.com